





Apteekkari kasausohje




Apteekkarin kasaus, asennus ja säätö




1




2




3




B





A




C




4




Z	
250	175
275	200
300	225
350	275
400	325
450	375
500	425
550	475
600	525




5




6




7




8




9













10






11





1 Irroita ovi



2 Asenna ovi



3 Irroita kisko



4 Asenna kisko

